



35mm 240V Tubular Motor (Electronic Limits) Programming Instructions.



To ADD a new Remote or Channel

1. Using a remote or channel ALREADY PROGRAMMED to the motor, wake the motor up by pressing and holding the STOP (middle) button for more than three seconds. *(The motor will jog)*
2. Press briefly the UP button on the NEW remote/channel within 10 seconds. *(The motor will jog)*

To DELETE a Remote or Channel

1. On the remote or channel to be deleted, wake the motor up by pressing and holding the STOP (middle) button for more than three seconds. *(The motor will jog)*
2. Using a paperclip or similar, within 10 seconds, press the programming button on the back of the remote control for three seconds. *(The motor will jog)*

To DELETE any Limit

Note—the top limit cannot be deleted, only adjusted

1. Move the blind to the limit to be deleted
2. Press and hold the programming button on the back of the remote control for approximately seven seconds. *(The motor will jog)*
3. *NOTE: The motor will jog twice, keep the button depressed until the second jog after 7 secs.*

To switch from Automatic movement to manual movement (or vice versa)

1. Wake the motor up by pressing the STOP (middle) button for 5 seconds. *(The motor will jog)*
2. Within 10 seconds, press the STOP button briefly. *(The motor will jog)*

To return to factory mode

1. On the motor, press the program button for more than SEVEN seconds.
2. *NOTE: The motor will jog twice, keep the button depressed until the second jog after 7 secs.*
3. *Once reset, the motor will do a double jog*



35mm 240V Electronic Tubular Motor Programming Instructions.

To Pair the Motor and a Remote/Channel

1. Using a paperclip or similar, press and hold the programming (prog.) button in the head of the motor for more than three seconds to wake the motor up. *(The motor will jog)*
2. Select the channel required on the remote (if applicable) and press briefly the UP (top) button within 10 seconds. *(The motor will jog)*

To change the rotation direction

1. Press the STOP (middle) button of the programmed remote/channel for 7 seconds *(The motor will jog)*
2. Press briefly the DOWN (bottom) button within 10 seconds. *(The motor will jog)*

To set the Top and Bottom limits

Note—when setting any limits, if there is no action within 30 seconds, the motor will exit limit setting mode.

1. Using a paperclip or similar, press and hold the prog. button found on the back of the remote control for more than three seconds to enter limit setting mode. *(The motor will jog)*
2. Set the top limit first: Press UP to move the blind to the desired top limit.
3. Press and hold the prog. button on the back of the remote control for more than three seconds to store that limit. *(The motor will jog)*
4. Press Down to move the blind to the desired bottom limit.
5. Press and hold the prog. button on the back of the remote control for more than three seconds to store that limit. *(The motor will jog)*
6. NB—With the blind at the bottom limit, Press and hold the prog. button on the back of the remote control for more than three seconds to exit limit setting mode. *(The motor will jog)*

To set intermediate stopping positions

Note—it is possible to set up to 6 intermediate stopping positions including top and bottom. An up/down command will send the motor to the next limit in that direction. To go straight to the top or bottom limit, double press the up/down button.

Note-The top and bottom limits must be set and stored prior to setting any intermediate stopping positions.

1. Press UP or DOWN to move the blind to the desired intermediate stopping position.
2. Press and hold the prog. button on the back of the remote control for more than three seconds to enter limit setting mode. *(The motor will jog)*
3. Release, then press and hold the prog. button on the back of the remote control for more than three seconds to store that limit. *(The motor will jog)*

To adjust a Limit

1. Move the blind to the limit to be adjusted
2. Press and hold the prog. button on the back of the remote control for more than three seconds to enter limit setting mode. *(The motor will jog)*
3. Press UP or DOWN to move the blind to the desired new position.
4. Press and hold the prog. button on the back of the remote control for more than three seconds to store the limit. *(The motor will jog)*